

## USER MANUAL ADBLUE EMULATOR FORD





- www.canbusemulator.com/en
- +90 530 937 46 36
- s erenakarsubasi

## **Required Instructions**



First of all, the vehicle must not be working. Then, as shown above, unscrew the fuse box 33 and the fuse 36 in the marked place.

Then insert the Adblue emulator into the OBD socket.

You can then start the vehicle.

The OBD socket is shown in the picture below.

