

# USER MANUAL

## Adblue Removal Emulator for Ford Cargo

**EURO 5**



 [www.canbusemulator.com](http://www.canbusemulator.com)

 +90 530 939 55 10

- Black cable which has white stripe -> to vehicle body chassis (terminal 31) Black Cable

- Blue cable which has black stripe (CAN Low) - Emulator's brown cable

- Yellow Cable which has blue stripe (CAN High) - Emulator's white cable

- Turn off ignition

- Wait for stop everything that works with the SCR

- Disconnect the OBD Connector and install it in the colors indicated above.

- Replace the back of the OBD connector.

4 Chasis Black Cable which has white stripe

6 CAN High Yellow Cable which has blue stripe

14 CAN Low Blue Cable which has black stripe


- Connect the red voltage lead to the ignition voltage.(terminal 15)

- Remove the terminal 15 and 30 fuses you can see in the picture.

- Switch on the ignition and check the adblue level in the display. 50% or 70% will appear.

- Erase with Diagnostic tools if there are any fault records.

- That's all



/

