




# USER MANUAL

IVECO DAILY EURO 6.2 ADBLUE EMULATOR

**EURO 6.2**



 [www.canbusemulator.com](http://www.canbusemulator.com)

 +90 530 937 46 36

 [erenakarsubasi](https://t.me/erenakarsubasi)

# Iveco Daily Euro 6.2 ADBLUE EMULATOR

REGENERATION IS RECOMMENDED BEFORE INSTALLATION



PULL THE 40 AMP F02 FUSE FROM THE FUSE BOX



EMULATOR	CAN
YELLOW	WHITE
GREEN	ORANGE

EMULATOR	OBD
RED	PIN16 (+)
BLACK	PIN 5 OR PIN4 (-)





ADBLUE LEVEL MUST BE 21 AFTER INSTALLATION

