



USER MANUAL

Daf LF EMULATOR INSTALLATION

EURO 6



 www.canbusemulator.com

 +90 530 937 46 36

 [erenakarsubasi](https://t.me/erenakarsubasi)

Daf LF EMULATOR INSTALLATION

You can connect to Adblue tank socket

You need to remove the NOx1 NOx2 Adblue tank level socket, then find the can H can low contact and minus ends to the adblue tank level socket.

Adblue tank level socket.	EMULATOR
CAN H Cable	YELLOW Cable
CAN LOW Cable	GREEN Cable
+15 (after ignition)	RED Cable
The chassis must be connected to the black cable of the emulator.	